

QUICK START-UP GUIDE

elite one - three

If you have questions about your machine, DON'T contact your dealer; please call Lobster Sports directly at 800.210.5992

1. Align the white line marker on bottom of machine directly over the baseline and center machine on the court as shown to the right.
2. Lift off the ball hopper, flip upside down, and place on top of machine. Press down firmly to make sure the ball hopper is secure.
3. Place 3-4 balls in the hopper, power on machine, turn FEED knob from 2-12 (12 seconds is the slowest setting) and wait 20 seconds for the machine to start feeding. Confirm the elevation, speed, and spin are how you want; adjust if necessary.
4. Once you have the machine set to your liking, turn the POWER off and fill hopper with tennis balls.
5. When ready, turn the POWER back on. There is a 20 second delay allowing you time to get to the other side of the court before the first ball throw.

